







G1-X1 BATTERY POSITIVE	G1-GP1-X2 BATTERY NEGATIVE
	
BATT.W.H.	BATT.W.H.
<b>X86-A</b> FUSIBLE LINK SUPPLY	<b>X86-B</b> START & GENERATOR
	
BATT.W.H.	BATT.W.H.
<b>X86-C</b> DC-SENSE	<b>X86-D</b> BATTERY WIRING HARNESS GROUND
	
BATT.W.H.	BATT.W.H.