



A133-X1 RADIO, CLOCK & CD PLAYER	A133-X2 POWER ANTENNA	A133-X3 DIVERSITY ANTENNA
<p>C19 C18 C20 B7 B8 A7 A8</p> <p>C1 C3 C2 B1 B2 A1 A2</p>	<p>A</p> <p>B</p>	<p>A</p> <p>B</p>
M.W.H.	M.W.H.	M.W.H.