





| | | | | | |
|----------------------------------|---------------------------|----------------------------------|---------------------------|----------------------------------|---------------------------|
| A84-V6-X1 A84-V6SC-X1 | POWERTRAIN CONTROL MODULE | A84-V6-X2 A84-V6SC-X2 | POWERTRAIN CONTROL MODULE | A84-V6-X3 A84-V6SC-X3 | POWERTRAIN CONTROL MODULE |
|----------------------------------|---------------------------|----------------------------------|---------------------------|----------------------------------|---------------------------|



| | |
|------------------|---------------------------|
| A84-V8-X1 | POWERTRAIN CONTROL MODULE |
|------------------|---------------------------|



| | |
|------------------|---------------------------|
| A84-V8-X2 | POWERTRAIN CONTROL MODULE |
|------------------|---------------------------|

